

Motorlager

ABB

<u>Typ</u>	<u>Byggstorlek</u>	<u>Lager drivsida</u>	<u>Lager fläktsida</u>
MT. M	63 A.B	6202-Z-2Z	6202-Z-2Z
MT. M	71 A.B	6203-Z-2Z	6202-Z-2Z
MT. M	80 A.B	6204-Z-2Z	6203-Z-2Z
MT. M	90 S.L	6305-Z-2Z	6204-Z-2Z
MT	100 LA. LB	6306-Z-2Z	6205-Z-2Z
M	100 L	6305-Z-2Z	6205-Z-2Z
M	100 LA. LB	6306-Z-2Z	6205-Z-2Z
<hr/>			
MBT. M2 AA	112 A.B	6206-Z-2Z	6205-Z-2Z
M2 AA	112 MB	6206-2Z	6206-2Z
MBL. M	112	6306-Z-2Z	6205-Z-2Z
MBT M2 AA	132	6208-Z-2Z	6206-Z-2Z
M2 AA	132 SC. MB. MC	6208-2Z	6208-2Z
MBL. M	132	6308-Z	6206-Z
MBT	160	6209-Z	6209-Z
M	160	6309	6307
<hr/>			
M	180	6310.C3 (N 310)	6309.C3
MBT	180	6211	6210
M	200	6312.C3 (N 312)	6310.C3
MBT	200	6213	6211
M2AA	200	6312	6210
M	225	6313.C3 (N 313)	6312.C3
MBT	225	6214	6214
M2AA	225	6313	6212
<hr/>			
MBB	3	6203.C3	6202.C3
MBB	5	6204.C3	6203.C3
MBB	7. 8	6205.C3	6204.C3
MBB	9. 10	6206.C3	6205.C3
MBB	11. 12	6307.C3	6206.C3

