

Motorlager

Leroy-Somer

<u>Typ</u>	<u>Byggstorlek</u>	<u>Lager drivsida</u>	<u>Lager fläktsida</u>
LS	56	6201	6002
LS	63 E	6201	6002
LS	63 F	6202	6202
LS	71	6202	6201
LS	80	6204	6203
LS	90	6205	6204
LS	100, 112	6206	6205
LS	112 S	6208	6207
LS	132, 132 M	6308	6307
<hr/>			
LS	160	6309-Z.C3	6210-Z.C3
LS	180 MT	6310-Z.C3	6210-Z.C3
LS	180 L	6310-Z.C3	6212-Z.C3
LS	200 LT	6312-Z.C3	6212-Z.C3
LS	200 L	6213-Z.C3	6214-Z.C3
LS	225	6314.C3	6214.C3
LS	225 T	6312-Z.C3	6214.C3
LS	250	6315.C3	6215.C3
LS	280	6317.C3	6317.C3
LS	280 ST	6315.C3	6215.C3
LS	315 ¹⁾	6317.C3	6317.C3
LS	315	6320.C3	6317.C3
<hr/>			
PLS	160	6310.C3	6210-Z.C3
PLS	160 MT	6210-Z.C3	6307-Z.C3
PLS	180 MT	6312.C3	6210-Z.C3
PLS	180 L	6312.C3	6212.C3
PLS	200 MT	6313.C3	6312.C3
PLS	200 L	6314.C3	6313.C3
PLS	225	6314.C3	6313.C3
<hr/>			

¹⁾=Kan sitta rullager i motorn.